






Tipuri Constructive si Echivalente

Denumire					
Z,A,B,C,D	<i>Classical PB V</i>	Delta	Oleostatic	VB Classical	V DIN 2115
SPZ,SPA,SPB,SPC	<i>Ultra PLUS Wedge</i>	SK Wedge	SP Wedge	SK Wedge	V DIN 7753
XPZ,XPA,XPB,XPC	<i>Ultra PLUS CRE</i>	Super HC MN	Linea-X	Super TX	V FO Wedge
QXPZ,QXPA,QXPB,QXPC,	<i>Quattro PLUS CRE (EPDM)</i>	Quad Power 4	None	Super E Power	V FO Pioneer
QSPZ,QSPA,QSPB,QSPC	<i>Quattro PLUS TW</i>	None	None	Red Power 3	V Advance
USPB,USPC	<i>Ultra PLUS 150</i>	Predator	None	Blue Power	V Power
XL, L, H, XH, XXH	<i>Classical Timing</i>	Power Grip Classical	Isoran Classical	ZR	Synchrombelt Classical
5 MM, 8MM, 14MM PITCH HTD	<i>HTD</i>	Power Grip HTD	RPP	HTD	Synchrombelt HTD
8MXP, 14MXP	<i>Torque Drive Plus 3</i>	Power Grip GT3	RPP Silver	Omega HP	Synchroforce CXP
PH,PJ,PK,PL,PM	<i>PolyDrive PLUS</i>	Micro V	PV Ribbed	RB Ribbed	Multi Rib